What is the relationship between the mass of a damped spring-block oscillator {52.48g, 60.94g, 69.72g, 86.51g, 93.47g} and the damping ratio?

Word count: TBD

# Table of Contents

1	Intr	roduction	1
	1.1	The Research Question	1
	1.2	Background Information	1
	1.3	Hypothesis	2
<b>2</b>	Res	earch Design	4
	2.1	Variables	4
	2.2	Apparatus and Materials	6
	2.3	Methodology	7
	2.4	Preliminary Trials	8
	2.5	Risk Assessment	9
3	Res	ults	10
	3.1	Raw Data	10
		3.1.1 Qualitative Data	10
		3.1.2 Quantitative Data	10
	3.2	Data Processing	11
		3.2.1 Transformation	11
		3.2.2 Uncertainty Analysis	13
	3.3	Graphical Interpretation	15
4	Con	nclusion	16
	4.1	Evaluation	16
	4.2	Extensibility	16

## 1 Introduction

This essay extends the investigation of simple harmonic motion by studying the damping force of a damped oscillator submerged in water, aiming to scrutinize the relationship between the mass of the block and the damping ratio. By scrutinizing this relationship, the study aims to offer valuable insights that can inform the design of systems seeking to optimize damping levels for safety-related objectives.

#### 1.1 The Research Question

What is the relationship between the mass of a damped spring-block oscillator {52.48g, 60.94g, 69.72g, 86.51g, 93.47g} and the damping ratio?

#### 1.2 Background Information

An ideal and rather theoretical spring-mass system oscillates indefinitely, producing an ongoing sine or cosine curve. In reality, there will be a damping force that can be as minimally consequential as air resistance or as observable as viscous drag in a liquid. Anyway, energy is dissipated to the surroundings and hence the amplitude will gradually decrease until the oscillation stops. The extent to which the viscous drag force, modeled by Stoke's law, diminishes the oscillatory motion submerged in water depends on the mass of the oscillator. This investigation delves into the relationship between the independent variable of mass m, and the dependent variable of the damping ratio  $\zeta$ . The mass set used in the system consists of spheres of equal radii but different densities.

Stoke's law determines the drag force acting upon an object traveling through a fluid. It is proportional to the object's velocity and is given by the following per the Physics Data Booklet, in Newtons

$$F_d = 6\pi r \eta v$$

This law holds iff. the object speed is low such that the flow to be *laminar*, and the object is *spherical*.

1.3 Hypothesis 1 INTRODUCTION

**Assumption 1.** The damping force is the viscous drag force.

Moreover, the motion of the oscillator is modeled by the following differential equation, with the damping force proportional to velocity (Miller, 2004):

$$m\ddot{x}(t) + b\dot{x}(t) + kx(t) = 0 \tag{1}$$

The damping ratio  $\zeta$  is defined as the ratio of the damping coefficient to the critical damping coefficient — the damping coefficient when the system returns to equilibrium without completing an oscillation. That is

$$\zeta = \frac{b}{c_c} = \frac{b}{2mw_0}$$

where  $w_0$  is the natural frequency of the system

$$w_0 = \sqrt{\frac{k}{m}}$$

$$\implies \zeta = \frac{b}{2\sqrt{mk}}$$

## 1.3 Hypothesis

Suppose that the constant of proportionality of the damping force with speed is given by  $b = 6\pi r\eta$ , per Stoke's law. Then

$$6\pi r \eta = 2\zeta \sqrt{mk}$$
$$9\pi^2 r^2 \eta^2 = \zeta^2 mk$$
$$\frac{\zeta^2}{m^{-1}} = \frac{9\pi^2 r^2 \eta^2}{k}$$

**Proposition 1.** For a fixed sphere radius r and viscosity  $\eta$ ,

$$\zeta^2 \propto m^{-1} \tag{2}$$

1.3 Hypothesis 1 INTRODUCTION

Equivalently, the graph  $\zeta^2/m^{-1}$  is ideally a straight line, although not necessarily passing through the origin, as some form of systematic errors are expected.

Proposition 1 has a few dependencies that may affect its accuracy. It relies on Assumption 1, which, in turn, requires that the flow is laminar. This is a reasonable assumption given that the spheres are relatively small, and the speed is low; the potential for turbulence is insignificant and even if present, the impact is minimal. Furthermore, the buoyancy force on the object

$$F_b = \rho g V$$

is always present but is not modeled in the differential equation at eq. (1). Notwithstanding, the absence of considerations of buoyancy has negligible impact on precision. The setup involves spheres of radius  $2.5 \,\mathrm{cm}$  and water of density  $997 \,\mathrm{kg}\,\mathrm{m}^{-3}$ , then

$$F_b \approx 10 \times 1000 \times \frac{4}{3}\pi (2.5 \times 10^{-2})^3 < 1$$
N

Null hypothesis  $(H_0)$ : There is no relationship between the mass and the damping ratio. Alternative hypothesis  $(H_1)$ : There is a relationship between the mass and the damping ratio.

# 2 Research Design

## 2.1 Variables

Vari	ables	Explanation	Measurement		
Independent	Mass m	The masses of the spherical	Measured using an electric		
		metal bobs	balance, to two d.p. with		
			uncertainty $\pm 0.01$ g		
Dependent	Peak Ampli-	At least 5 consecutive	Ruler, with uncertainty		
	tude	peaks, if the oscillation	$\pm 0.1 \mathrm{cm}$		
		does not stop before the			
		5th peak, will have their			
		heights measured. These			
		datasets are used then to			
		compute the damping ra-			
		tio.			

Table 1: Variables of investigation

Variable	Rationale	Means of Control			
Liquid viscosity	To keep the drag coeffi-	Using water from the			
	cient per Stoke's Law con-	same source throughout			
	stant	the experiment, and keep			
		the room temperature			
		constant by turning off the			
		air conditioning. Unknown			
		uncertainty			
Radius of the sphere	This is so that the drag	Using a set of spherical			
	force, per Stoke's law, is	masses of the same diam-			
	constant	eter			
Spring constant	This is so that the natural	Using the same spring			
	frequency of the system is	throughout the experi-			
	constant	ment. Read from the label			
		of on the box.			
Initial amplitude, $A_0 =$	So that the damping ratio	Pulling the spring down by			
5cm	is not affected by the initial	equal distances for every			
	conditions	mass. Measured by a ruler			
		and hence has uncertainty			
		$\pm 0.1 \mathrm{cm}$			
Damping coefficient	Linearizes relationship be-	Previous means of control			
	tween damping ratio and	keep fluid viscosity and ob-			
	mass	ject dimensions constant,			
		so the damping coefficient,			
		which depend on these,			
		will be constant.			

Table 2: Control variables

### 2.2 Apparatus and Materials




Figure 1: The experimental setup

- 1. Ruler ( $\pm 0.1$ cm)
- 2. Electric balance  $(\pm 0.01g)$
- 3. Spring with spring constant  $k = ??? \text{N m}^{-1}$
- 4. Mass set with five spherical masses of diameter ???cm, and masses

(a) 
$$m_1 = ???g$$

- 5. Beaker ([dimensions here])
- 6. Tap water ([volume here])
- 7. Camera keeps a record for future reference
- 8. Thermometer to ensure that the liquid stays at a constant temperature
- 9. Retort stand
- 10. Clamp

#### 2.3 Methodology

- 1. Take a piece of metal wire, and cut into segments of 3cm in length. [may change to scotch tape]
- 2. Arrange the masses in increasing order, i.e.  $m_1 < m_2 < ... < m_n$ , where n is the number of masses in the mass set.
- 3. Fill in the beaker with AmL of tap water
- 4. Measure the temperature of the water, and record as  $T_0$
- 5. Attach the clamp to the retort stand.
- 6. Lean the ruler vertically against the retort stand.
- 7. Place the beaker directly under the clamp such that the clamp lies at the center of the beaker in bird's eye view.
- 8. For i from 1 to n inclusive, repeat the following
  - (a) Take the *i*th mass,  $m_i$ , and attach its hook to the spring.
  - (b) Take a piece of metal wire, wrap it as many times as possible across the diagonal (explanation to be improved), fix and reinforce the connection between the mass and the spring.
  - (c) Attach the spring-mass pair to the clamp and let the mass hang freely.
  - (d) Adjust the height of the clamp so that the mass is submerged in the water.
  - (e) Measure the height of the mass from the surface of the desk, and record as  $h_0$
  - (f) Adjust the vertical camera position such that it levels with the reading  $(h_0 \frac{A_0}{2})$ cm to minimize parallax error of the camera.
  - (g) For j from 1 to 3 inclusive, repeat the following

- i. Pull the mass down by  $A_0$  cm by reading  $h_0 A_0$  from the ruler at eye level. The center of the mass should be the height a which readings are taken.
- ii. Start the camera recording.
- iii. Release the mass.
- iv. Record the clip until the 5th negative peak is reached.
- v. Save the clip as Mass\_i\_Trial\_j.mp4
- vi. Open the clip in a video viewer.
- vii. Identify the first 3 negative peaks, one in each cycle.
- viii. Record the respective heights above the desk as  $\{h_k\}_{k=1}^5$ .
- ix. Then the corresponding peak amplitudes are  $A_k = h_0 h_k$
- (h) Take the average values across the three trials for each peak amplitude.

### 2.4 Preliminary Trials

Preliminary trials were conducted to identify and resolve potential challenges, as well as to refine the experimental conditions. Initially, segments of metal wire were used to attach the masses to the spring, but this approach led to inconsistent wrapping and slipping. To improve the attachment's security and uniformity, Scotch tape was tested and found to be more effective, significantly reducing variability and enhancing setup repeatability. Precise measurement of the initial height  $(h_0)$  and consistent displacement of the mass by  $A_0$ , cm were also challenging. Aligning the ruler vertically against the retort stand and centering the mass over the beaker proved crucial for accuracy. Adjustments to the clamp and careful ruler leveling minimized parallax error, further reduced by positioning the camera at eye level.

## 2.5 Risk Assessment

Consideration	Relevance and Mitigation
Safety	All valuable assets are kept away from the experimental setup to
	prevent accidental detachments of the spring-mass system lead-
	ing to the mass being thrown out and causing damage. More-
	over, the amplitude was kept low to prevent fierce movements
	that can break the beaker or computer camera.
Ethical	No use of animals or human bodies involved. However, the
	recording selects the location and angle that avoids the storage
	and exposure of any personal information or objects of the lab
	owner, ensuring maximum privacy protection.
Environmental	The entire experiment aims to reuse the same water through-
	out to minimize water wastage. Furthermore, the spring was
	carefully pulled to prevent it from passing its elastic limit and
	become unusable for future experiments.

Table 3: Risk Assessment

## 3 Results

#### 3.1 Raw Data

#### 3.1.1 Qualitative Data

During the entire experiment, there is no spillage of water, which means that the volume is kept constant. Moreover, the spring is always able to return to its original length without any permanent deformation, indicating that the spring is not stretched beyond its elastic limit and that Hooke's Law applies throughout.

#### 3.1.2 Quantitative Data

Let m denote the mass of a bob, and  $A_n$  denote the n-th peak height.

$m \pm 0.01$ (g)	$A_1 \pm 0.1 \text{ (cm)}$					$A_2 \pm 0.1 \text{ (cm)}$				$A_3 \pm 0.1 \text{ (cm)}$					
52.48	2.9	2.9	2.8	2.8	2.9	1.7	1.8	1.7	1.7	1.7	1.0	1.0	1.0	1.1	1.0
60.94	2.9	3.0	3.0	2.9	3.0	1.8	1.9	1.8	1.8	1.8	1.1	1.1	1.1	1.2	1.1
69.72	3.1	3.1	3.1	3.1	3.1	1.9	2.0	1.8	1.9	1.9	1.2	1.2	1.2	1.3	1.2
86.51	3.3	3.3	3.3	3.3	3.3	2.1	2.1	2.2	2.1	2.1	1.4	1.4	1.4	1.4	1.3
93.47	3.5	3.3	3.4	3.3	3.5	2.4	2.2	2.4	2.2	2.2	1.5	1.5	1.5	1.5	1.5

Table 4: Raw data of peak amplitudes

### 3.2 Data Processing

#### 3.2.1 Transformation

Using the *logarithmic decrement* method per Inman (2008)

$$\delta = \ln\left(\frac{A_n}{A_{n+1}}\right) \text{ and } \delta = \frac{2\pi\zeta}{\sqrt{1-\zeta^2}}$$

where  $A_n$  and  $A_{n+1}$  denote any pair of consecutive peaks' heights.

It then follows that

$$\delta^2 = \frac{4\pi^2 \zeta^2}{1 - \zeta^2}$$

$$\delta^2 - \delta^2 \zeta^2 = 4\pi^2 \zeta^2$$

$$\delta^2 = \zeta^2 \left( 4\pi^2 + \delta^2 \right)$$

$$\zeta = \frac{\delta}{\sqrt{4\pi^2 + \delta^2}}$$

This step is encapsulated in the following Python snippet that belongs to an overall script for processing the data and generating the graph.

```
1 # Calculate the average damping ratio for each row in the dataframe
 2 def avgDampingRatio(row: pd.Series):
       ratios = np.array([]) # Create an empty array to store the damping ratios
        # Iterate over the range of peak indices
       for i in range(PEAK_IND[0], PEAK_IND[1] - 1):
          # Iterate over the range of peak indices starting from i+1
           # the purpose of this double loop is to calculate the damping
 8
 9
           # ratio between every possible pair of peaks
10
          for j in range(i + 1, PEAK_IND[1]):
               n = j - i # Calculate the number of cycles between i and j
delta = (1 / n) * math.log(
11
12
                    (row.iloc[i]) / row.iloc[j]
1.3
                ) # Calculate the logarithmic decrement between the peaks
14
                zeta = delta / math.sqrt(
                4 * (math.pi) ** 2 + delta**2
) # Calculate the damping ratio using the logarithmic difference
16
17
18
                ratios = np.append(
19
                    ratios, zeta
                ) # Append the damping ratio to the ratios array
21
       return np.average(ratios) # Return the average damping ratio
22
2.3
24 def processData():
      # reads the data tables and find the average across 5 trials
       df = averageData()
26
27
28
       # populate the column of damping ratio in the table for each mass
       df["Damping Ratio"] = df.apply(
30
31
            avgDampingRatio,
32
            axis=1.
```

Figure 2: Calculating the damping ratio with pandas in Python

Note that  $\overline{A_i}$  denotes the average value of the *i*-th peak across the five trials.

$m \pm 0.01 \; (10^{-3} \text{kg})$	$\overline{A_1} \ (10^{-2} \text{m})$	$\overline{A_2} \ (10^{-2} \text{m})$	$\overline{A_3} \ (10^{-2} \text{m})$	$\zeta^2/10^{-3}$ (unitless)
52.48	2.9	1.7	1.0	7.13
60.94	3.0	1.8	1.1	6.33
69.72	3.1	1.9	1.2	5.67
86.51	3.3	2.1	1.4	4.63
93.47	3.4	2.3	1.5	4.22

Table 5: Processed data

#### 3.2.2 Uncertainty Analysis

Let  $\Delta x$  denote the absolute uncertainty of x. For  $\Delta x \ll x$ , the uncertainty of f(x) is given by the following (Vacher, 2001)

$$\Delta f(x) \approx \frac{\mathrm{d}f(x)}{\mathrm{d}x} \cdot \Delta x$$

Let i, j such that i < j denote the indices of any two peaks, and also let  $\gamma = \frac{A_i}{A_{i+1}}$ , the following table summarizes the uncertainties involved in the calculation of the damping ratio from a pair of peaks indexed with (i, j).

Variable	Calculation	Absolute Uncertainty
m		0.01g
$m^{-1}$		$(m)^{-2} \cdot 0.01 \mathrm{g}^{-1}$
$A_k, \forall k$		0.1cm
$\gamma_{i,j}$	$\frac{A_i}{A_j}$	$\Delta \lambda_{i,j} = \frac{A_i}{A_j} \left( \frac{\Delta A_i}{A_i} + \frac{\Delta A_j}{A_j} \right)$
$\delta_{i,j}$	$\frac{1}{j-i} \ln \frac{A_i}{A_j}$	$\Delta \delta = \frac{\Delta \lambda}{\lambda}$
$\zeta_{i,j}$	$\frac{\delta}{\sqrt{4\pi^2 + \delta^2}}$	$\Delta \zeta_{i,j} = \frac{\mathrm{d}\zeta}{\mathrm{d}\delta} \cdot \Delta \delta$
$\zeta_{i,j}^2$		$2(\zeta_{i,j})\cdot(\Delta\zeta_{i,j})$

Table 6: Uncertainty Propagation

To implement the above logic in Python, the previous code snippet in fig. 2 is extended to include the uncertainty calculations.

```
1 # Calculate the average damping ratio for each row in the dataframe
 2 def avgDampingRatio(row: pd.Series, mode: Union["uncertainties", "vals"]):
       if type(row.iloc[-1]) == str:
           return 0
 5
       ratios = np.array([]) # Create an empty array to store the damping ratios
  6
       zetaSqUncertainties = np.array(
          []
 8
       ) # Create an empty array to store the uncertainties of the damping ratios
 10
       # Iterate over the range of peak indices
 11
       for i in range(PEAK_IND[0], PEAK_IND[1] - 1):
 12
           # Iterate over the range of peak indices starting from i+1
           # the purpose of this double loop is to calculate the damping
 13
           # ratio between every possible pair of peaks
 14
 15
           for j in range(i + 1, PEAK_IND[1]):
 16
               n = j - i # Calculate the number of cycles between i and j
17
               A_i, A_j = row.iloc[i], row.iloc[j] # Get the amplitudes of the peaks
18
 19
               if type(A_i) != float:
20
                   break
 21
 22
               qamma = A i / A j # Calculate the ratio of the amplitudes of the peaks
 2.3
 24
               delta = (1 / n) * math.log(
 25
                  gamma
 26
               ) # Calculate the logarithmic decrement between the peaks
 27
 28
               errAbsGamma = (A_i / A_j) * (
 29
                   (peakError / A i) + (peakError / A j)
 3.0
               ) # Calculate the absolute error of gamma
 31
 32
               # Calculate the absolute error of delta
 33
               errAbsDelta = errAbsGamma / gamma
 34
               zeta = delta / math.sqrt(
 3.5
 36
                   4 * (math.pi) ** 2 + delta**2
               ) # Calculate the damping ratio using the logarithmic decrement
37
3.8
 39
               dzeta ddelta = (
                  4 * math.pi**2 / math.pow(delta**2 + 4 * math.pi**2, 1.5)
 40
               ) # Calculate the derivative of zeta wrt delta
 41
42
 43
               errAbsZeta = (
 44
                  dzeta ddelta * errAbsDelta
45
               ) # Calculate the absolute error of zeta
 46
 47
               errAbsZetaSq = (
 48
                   2 * zeta * errAbsZeta
 49
               ) # Calculate the absolute error of the squared damping ratio
 50
               ratios = np.append(
 52
                   ratios, zeta
 53
               ) # Append the damping ratio to the ratios array
 54
 55
               zetaSqUncertainties = np.append(
                   zetaSqUncertainties, errAbsZetaSq
               ) # Append the uncertainty of the damping ratio
 57
58
 59
       return (
           np.average(ratios) if mode == "vals" else np.average(zetaSqUncertainties)
60
       ) # Return the average damping ratio or the average
61
       # uncertainties of the damping ratios based on the mode
62
```

Figure 3: Calculating the damping ratio with uncertainties in Python

93.47

1.92

 $m^{-1}(kg^{-1})$  $\Delta m^{-1} (\mathrm{kg}^{-1})$  $\Delta m/10^3 \; (\mathrm{kg})$  $\Delta \zeta^2 / 10^{-3}$ (unitless) 52.48 19.230  $0.003698 \approx 0.004$ 3.35 60.94 $0.002687 \approx 0.003$ 2.5316.39369.72 14.285 $0.002041 \approx 0.002$ 2.71 86.5111.494 $0.001321 \approx 0.001$ 2.42

Running the above script on the dataset produces the following table of uncertainties.

Table 7: Absolute uncertainties

 $0.001156 \approx 0.001$ 

10.753

## 3.3 Graphical Interpretation




Figure 4: Graph of  $\zeta^2$  against  $m^{-1}$ , with best-fit line and predicted line




Figure 5: Graph of  $\zeta^2$  against  $m^{-1}$  — literature review

The two graphs above show the relationship between the damping ratio squared and the inverse of the mass from the resultant dataset, with error bars plotted. The first graph, fig. 4, shows a scatter plot of the data points from section 3.2.2, with the best-fit line and the line predicted using Stoke's Law stated in the hypothesis proposition section. The data points suggest a linear relationship between  $\zeta^2$  and  $m^{-1}$ , with the Pearson correlation coefficient r = 0.684, suggesting a relatively strong linear trend.

## 4 Conclusion

#### 4.1 Evaluation

## 4.2 Extensibility

REFERENCES REFERENCES

## References

Inman, D. (2008). Engineering vibration fourth edition. Retrieved May 25, 2024, from https://api.pageplace.de/preview/DT0400.9780273785217\_A24571595/preview-9780273785217\_A24571595.pdf

- Miller, H. (2004). 13. natural frequency and damping ratio. DSpace@MIT. Retrieved May 14, 2024, from https://dspace.mit.edu/bitstream/handle/1721.1/34888/18-03Spring2004/NR/rdonlyres/Mathematics/18-03Spring2004/B76E6F4F-7B05-4DA0-A5A5-03FA4ACCB6B2/0/sup\_13.pdf
- Vacher, H. (2001). The taylor series and error propagation. Journal of Geoscience Education. Retrieved May 26, 2024, from https://cdn.serc.carleton.edu/files/nagt/jge/columns/CG16-v49n3p305.pdf