What is the relationship between the mass of a damped spring-block oscillator {52.48g, 60.94g, 69.72g, 86.51g, 93.47g} and the damping ratio?

Word count: TBD

Table of Contents

1	Intr	roduction	1
	1.1	The Research Question	1
	1.2	Background Information	1
	1.3	Hypothesis	2
2	Res	search Design	4
	2.1	Variables	4
	2.2	Apparatus and Materials	6
	2.3	Methodology	7
	2.4	Preliminary Trials	8
	2.5	Risk Assessment	9
3	Res	sults	10
	3.1	Raw Data	10
		3.1.1 Qualitative Data	10
		3.1.2 Quantitative Data	10
	3.2	Data Processing	11
		3.2.1 Transformation	11
		3.2.2 Uncertainty Analysis	13
	3.3	Graphical Interpretation	15
4	Con	nclusion	17
	4.1	Evaluation	18
		4.1.1 Strengths	18
		4.1.2 Weaknesses — Random Errors	18
		4.1.3 Weaknesses — Systematic Errors	18
		4.1.4 Extensions	18
Bi	bliog	graphy	19

1 Introduction

This essay extends the investigation of simple harmonic motion by studying the damping force of a damped oscillator submerged in water, aiming to scrutinize the relationship between the mass of the block and the damping ratio. By scrutinizing this relationship, the study aims to offer valuable insights that can inform the design of systems seeking to optimize damping levels for safety-related objectives.

1.1 The Research Question

What is the relationship between the mass of a damped spring-block oscillator {52.48g, 60.94g, 69.72g, 86.51g, 93.47g} and the damping ratio?

1.2 Background Information

An ideal and rather theoretical spring-mass system oscillates indefinitely, producing an ongoing sine or cosine curve. In reality, there will be a damping force that can be as minimally consequential as air resistance or as observable as viscous drag in a liquid. Anyway, energy is dissipated to the surroundings and hence the amplitude will gradually decrease until the oscillation stops. The extent to which the viscous drag force, modeled by Stoke's law, diminishes the oscillatory motion submerged in water depends on the mass of the oscillator. This investigation delves into the relationship between the independent variable of mass m, and the dependent variable of the damping ratio ζ . The mass set used in the system consists of spheres of equal radii but different densities.

Stoke's Law determines the drag force acting upon an object traveling through a fluid – proportional to the object's velocity and is the following per the Data Booklet, in Newtons

$$F_d = 6\pi r \eta v$$

This holds iff. the object's speed is low such that the flow is laminar, and the object is spherical.

1.3 Hypothesis 1 INTRODUCTION

Assumption 1. The damping force is the viscous drag force.

Moreover, the motion of the oscillator is modeled by the following differential equation, with the damping force proportional to velocity (Miller, 2004):

$$m\ddot{x}(t) + b\dot{x}(t) + kx(t) = 0 \tag{1}$$

The damping ratio ζ is defined as the ratio of the damping coefficient to the critical damping coefficient — the damping coefficient when the system returns to equilibrium without completing an oscillation. That is

$$\zeta = \frac{b}{c_c} = \frac{b}{2mw_0}$$

where w_0 is the natural frequency of the system

$$w_0 = \sqrt{\frac{k}{m}} \implies \zeta = \frac{b}{2\sqrt{mk}}$$

1.3 Hypothesis

Suppose that the constant of proportionality of the damping force with speed is given by $b = 6\pi r\eta$, per Stoke's law. Then

$$6\pi r \eta = 2\zeta \sqrt{mk}$$
$$9\pi^2 r^2 \eta^2 = \zeta^2 mk$$
$$\frac{\zeta^2}{m^{-1}} = \frac{9\pi^2 r^2 \eta^2}{k}$$

Proposition 1. For a fixed sphere radius r and viscosity η ,

$$\zeta^2 \propto m^{-1} \tag{2}$$

Equivalently, the graph ζ^2/m^{-1} is ideally a straight line, although not necessarily passing through the origin, as some form of systematic errors are expected.

1.3 Hypothesis 1 INTRODUCTION

Proposition 1 has a few dependencies that may affect its accuracy. It relies on Assumption 1, which, in turn, requires that the flow is laminar. This is a reasonable assumption given that the spheres are relatively small, and the speed is low; the potential for turbulence is insignificant and even if present, the impact is minimal. Furthermore, the buoyancy force on the object

$$F_b = \rho q V$$

is always present but is not modeled in the differential equation at eq. (1). Notwithstanding, the absence of considerations of buoyancy has negligible impact on precision. The setup involves spheres of radius 2.5cm and water of density 997kg m⁻³, then

$$F_b \approx 10 \times 1000 \times \frac{4}{3}\pi (2.5 \times 10^{-2})^3 < 1$$
N

Null hypothesis (H_0) : There is no relationship between the mass and the damping ratio. Alternative hypothesis (H_1) : There is a relationship between the mass and the damping ratio.

2 Research Design

2.1 Variables

Varial	oles	Explanation	Measurement		
Independent Mass m		The masses of the spherical	Measured using an electric		
		metal bobs	balance, to two d.p. with		
			uncertainty ± 0.01 g		
Dependent Peak Am-		3 peaks will be measured.	Ruler, with uncertainty		
plitude		These data points are used	$\pm 0.1 \mathrm{cm}$		
		to compute the damping ratio.			

Table 1: Variables of investigation

Control Variables							
Variable	Rationale	Means of Control					
Liquid viscosity 0.85	To keep the drag coefficient	Using water from the					
	per Stoke's Law constant	same source throughout					
		the experiment, and keep					
		the room temperature					
		constant by turning off the					
		air conditioning. In fact,					
		during the experiment, the					
		room temperature was 27°C					
Radius of the sphere, $r =$	This is so that the drag	Using spherical masses of					
2.5cm	force, per Stoke's law, is	the same diameter					
	constant						
Spring constant, $k =$	This is so that the natural	Using the same spring					
$100{ m N}{ m m}^{-1}$	frequency of the system is	throughout the experiment.					
	constant	Read from the label on the					
		box.					
Initial amplitude, $A_0 = 5$ cm	So that the damping ratio	Pulling the spring down by					
	is not affected by the initial	equal distances for every					
	conditions	mass. Measured by a ruler					
		with $\pm 0.1 \mathrm{cm}$					
Damping coefficient	Linearizes relationship be-	Previous means of control					
	tween damping ratio and	keep fluid viscosity and ob-					
	mass	ject dimensions constant, so					
		the damping coefficient will					
		be constant.					

Table 2: Control variables

2.2 Apparatus and Materials




Figure 1: The experimental setup

- 1. Ruler $(\pm 0.1 \text{cm})$
- 2. Electric balance $(\pm 0.01g)$
- 3. Spring with spring constant $k = 100 \text{N m}^{-1}$
- 4. Mass set with five spherical masses of diameter 2.5cm
- 5. Beaker
- 6. Tap water ([volume here])
- 7. Camera keeps a record for future reference
- 8. Thermometer to ensure that the liquid stays at a constant temperature
- 9. Retort stand
- 10. Clamp

2.3 Methodology

- 1. Take a scrotch tape, and cut into segments of 8cm in length.
- 2. Arrange the masses in increasing order, i.e. $m_1 < m_2 < ... < m_n$, where n is the number of masses in the mass set.
- 3. Fill in the beaker with AmL of tap water
- 4. Measure the temperature of the water, and record as T_0
- 5. Attach the clamp to the retort stand.
- 6. Lean the ruler vertically against the retort stand.
- 7. Place the beaker directly under the clamp such that the clamp lies at the center of the beaker in bird's eye view.
- 8. For i from 1 to n inclusive, repeat the following
 - (a) Take the *i*th mass, m_i , and attach its hook to the spring.
 - (b) Take a piece of tape, wrap it as many times as possible across the point of connection.
 - (c) Attach the spring-mass pair to the clamp and let the mass hang freely.
 - (d) Adjust the height of the clamp so that the mass is submerged in the water.
 - (e) Measure the height of the mass from the surface of the desk, and record as h_0
 - (f) Adjust the vertical camera position such that it levels with the reading $(h_0 \frac{A_0}{2})$ cm to minimize parallax error of the camera.
 - (g) For j from 1 to 3 inclusive, repeat the following
 - i. Pull the mass down by A_0 cm by reading $h_0 A_0$ from the ruler at eye level. The center of the mass should be the height a which readings are taken.
 - ii. Start the camera recording.
 - iii. Release the mass.

- iv. Record the clip until the 5th negative peak is reached.
- v. Save the clip as Mass_i_Trial_j.mp4
- vi. Open the clip in a video viewer.
- vii. Identify the first 3 negative peaks, one in each cycle.
- viii. Record the respective heights above the desk as $\{h_k\}_{k=1}^5$.
- ix. Then the corresponding peak amplitudes are $A_k = h_0 h_k$
- (h) Take the average values across the three trials for each peak amplitude.
- (i) Measure the water temperature and wait until it stays constant at 27°C.

2.4 Preliminary Trials

Preliminary trials were conducted to identify and resolve potential challenges, as well as to refine the experimental conditions. Initially, segments of metal wire were used to attach the masses to the spring, but this approach led to inconsistent wrapping and slipping. To improve the attachment's security and uniformity, Scotch tape was tested and found to be more effective, significantly reducing variability and enhancing setup repeatability. Precise measurement of the initial height (h_0) and consistent displacement of the mass by A_0 , cm were also challenging. Aligning the ruler vertically against the retort stand and centering the mass over the beaker proved crucial for accuracy. Adjustments to the clamp and careful ruler leveling minimized parallax error, further reduced by positioning the camera at eye level.

2.5 Risk Assessment

Consideration	Relevance and Mitigation	
Safety	All valuable assets are kept away from the experimental setup to	
	prevent accidental detachments of the spring-mass system leading	
	to the mass being thrown out and causing damage. Moreover, the	
	amplitude was kept low to prevent fierce movements that could	
	break the beaker or computer camera.	
Ethical	No use of animals or human bodies involved. However, the record-	
	ing selects the location and angle that avoids the storage and ex-	
	posure of any personal information or objects of the lab owner,	
	ensuring maximum privacy protection.	
Environmental	The entire experiment aims to reuse the same water throughout	
	to minimize water wastage. Furthermore, the spring was carefully	
	pulled to prevent it from passing its elastic limit and becoming	
	unusable for future experiments.	

Table 3: Risk Assessment

3 Results

3.1 Raw Data

3.1.1 Qualitative Data

During the entire experiment, there is no spillage of water, which means that the volume is kept constant. Moreover, the spring is always able to return to its original length without any permanent deformation, indicating that the spring is not stretched beyond its elastic limit and that Hooke's Law applies throughout.

3.1.2 Quantitative Data

Let m denote the mass of a bob, and A_n denote the n-th peak height.

$m \pm 0.01$ (g)	$A_1 \pm 0.1 \text{ (cm)}$				$A_2 \pm 0.1 \text{ (cm)}$				$A_3 \pm 0.1 \text{ (cm)}$						
52.48	2.9	2.9	2.8	2.8	2.9	1.7	1.8	1.7	1.7	1.7	1.0	1.0	1.0	1.1	1.0
60.94	2.9	3.0	3.0	2.9	3.0	1.8	1.9	1.8	1.8	1.8	1.1	1.1	1.1	1.2	1.1
69.72	3.1	3.1	3.1	3.1	3.1	1.9	2.0	1.8	1.9	1.9	1.2	1.2	1.2	1.3	1.2
86.51	3.3	3.3	3.3	3.3	3.3	2.1	2.1	2.2	2.1	2.1	1.4	1.4	1.4	1.4	1.3
93.47	3.5	3.3	3.4	3.3	3.5	2.4	2.2	2.4	2.2	2.2	1.5	1.5	1.5	1.5	1.5

Table 4: Raw data of peak amplitudes

3.2 Data Processing

3.2.1 Transformation

Using the logarithmic decrement method per Inman (2008)

$$\delta = \ln\left(\frac{A_n}{A_{n+1}}\right) \text{ and } \delta = \frac{2\pi\zeta}{\sqrt{1-\zeta^2}}$$

where A_n and A_{n+1} denote any pair of consecutive peaks' heights.

It then follows that

$$\delta^2 = \frac{4\pi^2 \zeta^2}{1 - \zeta^2}$$

$$\delta^2 - \delta^2 \zeta^2 = 4\pi^2 \zeta^2$$

$$\delta^2 = \zeta^2 \left(4\pi^2 + \delta^2\right)$$

$$\zeta = \frac{\delta}{\sqrt{4\pi^2 + \delta^2}}$$

This step is encapsulated in the following Python snippet that belongs to an overall script for processing the data and generating the graph.

```
1 # Calculate the average damping ratio for each row in the dataframe
 2 def avgDampingRatio(row: pd.Series):
       ratios = np.array([]) # Create an empty array to store the damping ratios
       # Iterate over the range of peak indices
 5
       for i in range(PEAK_IND[0], PEAK_IND[1] - 1):
           # Iterate over the range of peak indices starting from i+1
          \# the purpose of this double loop is to calculate the damping
 8
 9
           # ratio between every possible pair of peaks
          for j in range(i + 1, PEAK_IND[1]):
10
11
              n = j - i # Calculate the number of cycles between i and j
              delta = (1 / n) * math.log(
12
                  (row.iloc[i]) / row.iloc[j]
13
               ) # Calculate the logarithmic decrement between the peaks
15
               zeta = delta / math.sqrt(
                  4 * (math.pi) ** 2 + delta**2
16
               ) # Calculate the damping ratio using the logarithmic difference
17
18
              ratios = np.append(
19
                  ratios, zeta
2.0
               ) # Append the damping ratio to the ratios array
21
22
      return np.average(ratios) # Return the average damping ratio
23
24 def processData():
      # reads the data tables and find the average across 5 trials
25
26
      df = averageData()
27
28
29
       # populate the column of damping ratio in the table for each mass
      df["Damping Ratio"] = df.apply(
3.0
31
           avgDampingRatio,
          axis=1,
32
33
```

Figure 2: Calculating the damping ratio with pandas in Python

Note that $\overline{A_i}$ denotes the average value of the *i*-th peak across the five trials.

$m \pm 0.01 \; (10^{-3} \text{kg})$	$\overline{A_1} \ (10^{-2} \text{m})$	$\overline{A_2} \ (10^{-2} \text{m})$	$\overline{A_3} \ (10^{-2} \text{m})$	$\zeta^2/10^{-3}$ (unitless)
52.48	2.9	1.7	1.0	7.13
60.94	3.0	1.8	1.1	6.33
69.72	3.1	1.9	1.2	5.67
86.51	3.3	2.1	1.4	4.63
93.47	3.4	2.3	1.5	4.22

Table 5: Processed data

3.2.2 Uncertainty Analysis

Let Δx denote the absolute uncertainty of x. For $\Delta x \ll x$, the uncertainty of f(x) is given by the following (Vacher, 2001)

$$\Delta f(x) \approx \frac{\mathrm{d}f(x)}{\mathrm{d}x} \cdot \Delta x$$

Let i, j such that i < j denote the indices of any two peaks, and also let $\gamma = \frac{A_i}{A_{i+1}}$, the following table summarizes the uncertainties involved in the calculation of the damping ratio from a pair of peaks indexed with (i, j).

Variable	Calculation	Absolute Uncertainty
m		0.01g
m^{-1}		$(m)^{-2} \cdot 0.01 \mathrm{g}^{-1}$
$A_k, \forall k$		0.1cm
$\gamma_{i,j}$	$\frac{A_i}{A_j}$	$\Delta \lambda_{i,j} = \frac{A_i}{A_j} \left(\frac{\Delta A_i}{A_i} + \frac{\Delta A_j}{A_j} \right)$
$\delta_{i,j}$	$\frac{1}{j-i} \ln \frac{A_i}{A_j}$	$\Delta \delta = \frac{\Delta \lambda}{\lambda}$
$\zeta_{i,j}$	$\frac{\delta}{\sqrt{4\pi^2 + \delta^2}}$	$\Delta \zeta_{i,j} = \frac{\mathrm{d}\zeta}{\mathrm{d}\delta} \cdot \Delta \delta$
$\zeta_{i,j}^2$		$2(\zeta_{i,j})\cdot(\Delta\zeta_{i,j})$

Table 6: Uncertainty Propagation

To implement the above logic in Python, the previous code snippet in fig. 2 is extended to include the uncertainty calculations.

```
1 # Calculate the average damping ratio for each row in the dataframe
 2 def avgDampingRatio(row: pd.Series, mode: Union["uncertainties", "vals"]):
       if type(row.iloc[-1]) == str:
 4
          return 0
 5
       ratios = np.array([]) # Create an empty array to store the damping ratios
       zetaSqUncertainties = np.array(
          []
 8
      ) # Create an empty array to store the uncertainties of the damping ratios
 9
       # Iterate over the range of peak indices
10
       for i in range(PEAK_IND[0], PEAK_IND[1] - 1):
11
12
           # Iterate over the range of peak indices starting from i+1
13
           # the purpose of this double loop is to calculate the damping
14
           # ratio between every possible pair of peaks
15
           for j in range(i + 1, PEAK IND[1]):
               n = j - i # Calculate the number of cycles between i and j
16
17
               A_i, A_j = row.iloc[i], row.iloc[j] # Get the amplitudes of the peaks
18
19
               if type(A_i) != float:
20
                  break
21
22
               gamma = A_i / A_j # Calculate the ratio of the amplitudes of the peaks
23
24
               delta = (1 / n) * math.log(
25
                  gamma
26
               ) # Calculate the logarithmic decrement between the peaks
27
               errAbsGamma = (A i / A j) * (
28
29
                   (peakError / A_i) + (peakError / A_j)
30
               ) # Calculate the absolute error of gamma
               # Calculate the absolute error of delta
32
33
               errAbsDelta = errAbsGamma / gamma
34
               zeta = delta / math.sqrt(
3.5
36
                  4 * (math.pi) ** 2 + delta**2
               ) # Calculate the damping ratio using the logarithmic decrement
37
38
               dzeta_ddelta = (
39
                  4 * math.pi**2 / math.pow(delta**2 + 4 * math.pi**2, 1.5)
40
41
                 # Calculate the derivative of zeta wrt delta
42
               errAbsZeta = (
43
                  dzeta ddelta * errAbsDelta
45
               ) # Calculate the absolute error of zeta
46
               errAbsZetaSq = (
47
                  2 * zeta * errAbsZeta
48
49
               ) # Calculate the absolute error of the squared damping ratio
5.0
51
               ratios = np.append(
                   ratios, zeta
53
               ) # Append the damping ratio to the ratios array
54
               zetaSqUncertainties = np.append(
                  zetaSqUncertainties, errAbsZetaSq
56
               ) # Append the uncertainty of the damping ratio
58
59
      return (
          np.average(ratios) if mode == "vals" else np.average(zetaSqUncertainties)
          # Return the average damping ratio or the average
61
     # uncertainties of the damping ratios based on the mode
```

Figure 3: Calculating the damping ratio with uncertainties in Python

Running the above script on the dataset produces the following table of uncertainties.

$\Delta m/10^3 \; (\mathrm{kg})$	$m^{-1}(kg^{-1})$	$\Delta m^{-1} (\mathrm{kg}^{-1})$	$\frac{\Delta \zeta^2 / 10^{-3}}{\text{(unitless)}}$
52.48	19.230	$0.003698 \approx 0.004$	3.35
60.94	16.393	$0.002687 \approx 0.003$	2.53
69.72	14.285	$0.002041 \approx 0.002$	2.71
86.51	11.494	$0.001321 \approx 0.001$	2.42
93.47	10.753	$0.001156 \approx 0.001$	1.92

Table 7: Absolute uncertainties

3.3 Graphical Interpretation




Figure 4: Graph of ζ^2 against m^{-1} , with best-fit line and predicted line




Figure 5: Graph of ζ^2 against m^{-1} — literature review

The two graphs above show the relationship between the damping ratio squared and the inverse of the mass from the resultant dataset, with error bars plotted. The first graph, fig. 4, shows a scatter plot of the data points from section 3.2.1, with the best-fit line and the line predicted using Stoke's Law stated in the hypothesis proposition section. The data points suggest a linear relationship between ζ^2 and m^{-1} , with the Pearson correlation coefficient r = 0.684. The second graph, fig. 5, shows the prediction line in comparison to the maximum and minimum-slope lines resulting from the propagation of uncertainty — indeed, the theoretical prediction does lie within the error bars of the data points.

4 Conclusion

This essay delved into the effect of mass m on the damping ratio ζ of a damped spring-block oscillator submerged in water, with the hypothesis that

$$\zeta^2 \propto m^{-1}$$

The results from the experiment suggest a linear relationship between the damping ratio squared and the inverse of the mass, with a Pearson correlation coefficient of 0.684, indicating a relatively strong linear trend. The theoretical prediction line falls within the interval of the maximum and minimum slopes due to the uncertainties in measurements, supporting the hypothesis that the damping ratio squared is inversely proportional to the mass, within the experimented range of 52.48 to 93.47 grams.

The observation that the relationship is not perfectly linear is a consequence of the uncertainties that arise from the limitations of measuring devices and human errors. One primary source of random error is the unintentional but inevitable extra force applied when releasing the spring in the liquid. Nonetheless, the mass set did not produce anomolies and massive systematic errors, suggesting that the environment and the experimental setup were controlled effectively. Proposition 1 suggested that the expected gradient, m_0 would be

$$m_0 = \frac{9\pi^2 r^2 \eta^2}{k}$$
$$= \frac{9\pi^2 (0.025)^2 (0.85)^2}{100}$$
$$\approx 4.011 \times 10^{-4}$$

The minimum and maximum slopes are -3.339×10^{-4} and 9.109×10^{-4} respectively, with the experimental gradient in between. This shows that the drag force on the oscillator in water can be estimated using Stoke's Law. The error propagation does create rather significant error bars due to the already small values of ζ^2 , particularly for smaller masses. However, this does accept the theoretical value and is expected since ζ^2 is very sensitive to a change in mass.

4.1 Evaluation 4 CONCLUSION

4.1 Evaluation

4.1.1 Strengths

Strength Observations

- ${\bf 4.1.2 \quad Weaknesses -- Random \ Errors}$
- ${\bf 4.1.3 \quad Weaknesses -- Systematic\ Errors}$
- 4.1.4 Extensions

BIBLIOGRAPHY BIBLIOGRAPHY

Bibliography

Inman, D. (2008). Engineering vibration fourth edition. Retrieved May 25, 2024, from https://api.pageplace.de/preview/DT0400.9780273785217_A24571595/preview-9780273785217_A24571595.pdf

- Miller, H. (2004). 13. natural frequency and damping ratio. DSpace@MIT. Retrieved May 14, 2024, from https://dspace.mit.edu/bitstream/handle/1721.1/34888/18-03Spring2004/NR/rdonlyres/Mathematics/18-03Spring2004/B76E6F4F-7B05-4DA0-A5A5-03FA4ACCB6B2/0/sup_13.pdf
- Vacher, H. (2001). The taylor series and error propagation. Journal of Geoscience Education.

 Retrieved May 26, 2024, from https://cdn.serc.carleton.edu/files/nagt/jge/columns/
 CG16-v49n3p305.pdf